



INSTRUCTION MANUAL




INCLUDED IN THE BOX:



INSTRUCTIONS FOR USE:

Check the power level by pressing the button.
Lights indicate power level as per below.

Warning: To preserve battery lifespan,
please use and recharge the power
bank at least once every 3 months.




100% 75% 50% 25%

CHARGE YOUR PHONE OR TABLET

Your COMPAC series power bank has dual output
ports with fast charge technology: USB port with
QC 3.0 protocol and USB Type-C with PD protocol
for devices that support smart charging.


Note: Fast charge not supported if both output
ports are being used simultaneously to charge
two devices.



RECHARGE YOUR POWER BANK

Your COMPAC series power bank can be charged using the included USB to USB-C cable. Connect the USB-C end to the USB-C port on the power bank, and plug the standard USB end into a suitable USB charger (5V/9V/12V) such as a phone/tablet mains adaptor, or computer USB port that supports power. The power bank may also be charged via a USB port equipped solar charger.

Note: For the safest, fastest charging, please use a PD compatible USB charger with your power bank.



SPECIFICATIONS

Capacity	18.5Wh / 5,000mAh
Input	TYPE-C :PD (5V/2.1A;9V/ 1.4A;12V/1A)
Output	TYPE-C:PD (5V/3A;9V/2A; 12V/1.5A) USB: QC3.0 (5V/2.1A;9V/ 2A;12V/1.5A)
Dimension	76 x 59 x 27mm
Weight	101g

WARNING:

Please use only the original or certified equivalent cable for charging your power bank.

WARRANTY STATEMENT

APPLICABLE ONLY TO PRODUCT SOLD IN AUSTRALIA

Brown & Watson International Pty Ltd of 1500 Ferntree Gully Road, Knoxfield, Vic., telephone (03) 9730 6000, fax (03) 9730 6050, warrants that all products described in its current catalogue will under normal use and service be free of failures in material and workmanship for a period of one (1) year (unless this period has been extended as indicated elsewhere) from the date of the original purchase by the consumer as marked on the invoice. This warranty does not cover ordinary wear and tear, abuse, alteration of products or damage caused by the consumer.

To make a warranty claim the consumer must deliver the product at their cost to the original place of purchase or to any other place which may be nominated by either BWI or the retailer from where the product was bought in order that a warranty assessment may be performed. The consumer must also deliver the original invoice evidencing the date and place of purchase together with an explanation in writing as to the nature of the claim.

In the event that the claim is determined to be for a minor failure of the product then BWI reserves the right to repair or replace it at its discretion. In the event that a major failure is determined the consumer will be entitled to a replacement or a refund as well as compensation for any other reasonably foreseeable loss or damage.

This warranty is in addition to any other rights or remedies that the consumer may have under State or Federal legislation.

IMPORTANT NOTE

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Distributed by

AUSTRALIA
Brown & Watson International Pty Ltd
Knoxfield, Victoria 3180
Telephone (03) 9730 6000
Facsimile (03) 9730 6050
National Toll Free 1800 113 443

NEW ZEALAND
Narva New Zealand Ltd
22-24 Olive Road PO Box 12556 Penrose
Auckland, New Zealand
Telephone (09) 525 4575
Facsimile (09) 579 1192

IS450
Issue 1 13.09.19